

Multispectral Fingerprint Imaging



Robert K. Rowe, Ph.D.

CTO & VP RD&E

505.272.7406

Rob.Rowe@Lumidigm.com

Topics

- Conventional fingerprint sensing
- Multispectral imaging (MSI) overview
- Use of MSI for spoof detection
- Use of MSI for biometric enhancement


Introduction

- One important element required for remote biometric authentication is a *sensor* capable of providing a high assurance of identity while maintaining a high degree of usability
 - Minimum requirements for strong identity assurance:
 - Accessible biometric with a high degree of specificity to an individual
 - Biometric sensor is resistant to spoofing attempts
 - Minimum requirements for enhanced usability:
 - Sensor able to be used across the range of common physiological and environmental conditions
 - Human-sensor interface is intuitive and simple

Background

Conventional Fingerprints Sensors


- Most fingerprint sensors measure skin features at, or very near, the surface of the finger
 - Example: optical frustrated total internal reflectance (TIR)




Background

Key Technical Issues with Current Fingerprint Sensors

- Poor quality prints degrade system accuracy and cause delays and user frustration
 - Dry skin
 - Wet skin
 - Poor contact
 - Poorly defined fingerprint features
- Current fingerprint sensors are susceptible to “spoofing”
 - Silicone, latex, gelatin



www.biometrics.org/bc2004/Presentations/Conference/1%20Monday%20September%2020/Mon_Ballroom%20E/4%20DHS%20Session/Latta_update.pdf



www.blackhat.com/presentations/bh-usa-02/bh-us-02-smith-biometric.ppt

Multispectral Imaging (MSI) Overview

Goals and Approach


- Goals: develop a fingerprint sensor that is **easy to use and hard to spoof**
 - Doesn't require specific skin characteristics
 - Doesn't require precise contact
 - Sensor collects multiple skin characteristics, which can be used to ...
 - ... provide strong spoof protection
 - ... provide additional biometric information beyond just the fingerprint
- Approach: Collect multicolor images of internal and external features of the skin
 - Multispectral imaging (MSI)

MSI Overview

System Description


■ Customized multispectral imager:

- Optical geometry laid out image subsurface skin
 - Avoid critical angle phenomena. Interrogate the skin, not the interface between the skin and sensor
- Use crossed linear polarizers
 - Preferential imaging of scattered (subsurface) light
- Use multiple illumination wavelengths
 - See different depths and structures in the tissue





MSI Overview

Relevant Fingertip Physiology



From S. Sangiorgi et al.,
“Microvascularization of the human digit
as studied by corrosion casting,” *J. Anat.*
204, 123 – 131 (2004)





Optical absorption due to blood
(Note: semi logarithm scale)

- The structure of capillaries immediately below the surface mirrors external epidermal ridges and contains other distinct features (e.g. arterioles)
- Blood has distinct and strong absorbance bands in the visible region
- An image of these capillaries represents a subsurface fingerprint
- The non-blood portions of skin also have distinct spectral characteristics

MSI Overview


Combining with Conventional Fingerprint Technology I

- Combine total internal reflectance (TIR) and multispectral imaging (MSI) to get advantages of both
 - TIR
 - High-contrast when ideal conditions exist
 - Familiar and accepted by the user community
 - MSI
 - Low-contrast but present under a wide range of conditions
 - Strong information on sample composition (spoof detection)




MSI Overview


Combining with Conventional Fingerprint Technology II



Optical skin biometric



Conventional fingerprint



MSI Wavelengths:
400, 445, 500, 574, 610nm + TIR Illum.


Spoof Detection

Easy Case - Simple Silicone Casting



TIR

Image made from a
silicone replica of a fingerprint




MSI

Spectral comparison of
silicone data and multiple people

Spoof Detection

Extreme Case - High-Fidelity Silicone Model



Spoof Detection

Thin Transparent Film on Skin



TIR




MSI (Average Image)

Biometric Determinations

Typical MSI Data and Fingerprint Extraction Process

Original
Image

*Processed and
Discarded*



Colors represent
internal spectral
structure

Intermediate
Image


*Processed and
Discarded*



Colors indicate
which multispectral
plane was used
(Black=all)

Identifying
Features

*Stored and
Used for Comparison*



Colors represent
ridge endings
(green o)
or bifurcations
(blue *)

- Currently using commercially available fingerprint software for performance assessments

- Neurotechnologija

Comparison of TIR and MSI Images

Good Quality Finger

Raw Image

Binary Image

TIR



MSI



3 planes
mapped to
RGB

Equivalent fingerprint features,
but MSI can see beyond the region of contact

Comparison of TIR and MSI Images Dry Finger Skin


Raw Image

Binary Image

TIR



MSI



3 planes
mapped to
RGB

Can use the combination of TIR and MSI images to generate one composite fingerprint image even in adverse conditions

Biometric Determinations

Summary of Biometric Studies to Date

■ Office environment

- 602 samples taken on 15 people, 4 fingers each, 16 days
- Standard fingerprint sensor produced an equal error rate of ~20%
 - 4 individuals had dry fingers
- Multispectral imager produced an error rate of 0.7% using an off-the-shelf fingerprint software package
- MSI + TIR: EER=0.4%



TIR



MSI

■ Dry fingers

- Clay desiccant used to dry a finger used for 20-sample data collection
- Standard fingerprint sensor failed to verify 17 / 20 images
- Multispectral imager correctly verified all images


■ Minimal contact

- 20 samples taken with finger lightly touching sensor
- Standard fingerprint sensor failed to verify 19 / 20 images
- Multispectral imager correctly verified all images

Summary

- Multispectral imaging of the finger provides a means to detect complementary biometric features of the finger
- MSI provides the ability to increase the ease of collection and information content of fingerprint images
- MSI+TIR development goal is improved security and usability

Usability



Acknowledgements and Contact Details

- This material is based in part upon work supported by the Air Force Research Laboratory, Rome, NY under Contract No. FA8750-04-C-0190.
- Portions of this work are the result of a partnership between Lumidigm and Cross Match Technologies
- Contact information:

Rob.Rowe@Lumidigm.com

505.272.7406